


# Autocorrect & Keyboard Options

## Auto-correction and spell checking

For many languages, iPad uses the active dictionary to correct misspellings or make suggestions as you type. When iPad suggests a word, you can accept the suggestion without interrupting your typing. For a list of supported languages, see [www.apple.com/ipad/specs](http://www.apple.com/ipad/specs).



**Accept the suggestion:** Type a space, punctuation mark, or return character.

**Reject a suggestion:** Tap the "x" next to the suggestion.

Each time you reject a suggestion for the same word, iPad becomes more likely to accept the word. iPad may also underline words you've already typed that might be misspelled.

**Replace a misspelled word:** Tap the underlined word, then tap the correct spelling. If the word you want doesn't appear, just retype it.

**Turn auto-correction or spell checking on or off:** Go to Settings > General > Keyboard.

## Keyboard layouts

On iPad, you can type with a split keyboard that's at the bottom of the screen, or undocked and in the middle of the screen.



**Adjust the keyboard:** Touch and hold , then:

- *Use a split keyboard:* Slide your finger to Split, then release.
- *Move the keyboard to the middle of the screen:* Slide your finger to Undock, then release.
- *Return to a full keyboard:* Slide your finger to Dock and Merge, then release.
- *Return a full keyboard to the bottom of the screen:* Slide your finger to Dock, then release.

**Turn Split Keyboard on or off:** Go to Settings > General > Keyboard > Split Keyboard.